
# **Super Duper Parts**











PART	CODE
Camfollower Assembly	SP5L
Rotor Spindle	SD107
Side Plate Nylon Bearings	SP110
Power Nozzle	SP1
Nozzle Clamp	SP2
Cam Service Kit, bearings, seals, o ring and circlip only	SD900
400m of 5mm Galv Wire Rope with fittings	SD1
400m of 5mm Stainless Steel Wire Rope with fittings	SD2

### **CAM**



SD106

PART	CODE
Cam and Bearing Housing	SD106
Bearing Top	BEAR6015
Circlip	CIRCLIP75
Seal	SEAL75X115
SS 304 Bolt	M10X35SS
Bearing Bottom	BEAR6016
SS Nyloc Nut	NYLOC10SS

PART	CODE
Rotor Spindle (tapered S/S pipe that carries bearings)	SD107
O ring	ORING90X5
Galv Bolt with Nut	M10X40G
Spring Washer	WASHERSP10
Cam Service Kit, bearings, seals, O ring and circlip only	SD900

# **CAMFOLLOWER**











SP5L

PART	CODE
Bolt with grease nipple	SP5L/B
16mm SS Flat Washer	SP5L/C
Bush S/S	SP5L/D
Bearing Camfollower	SP5L/E
Complete Assembly	SP5L




SP5L/C

SL/C SP5L/D

SP5L/E


SPRINGS	
	P
SP7	SP8
SP3/3	SP21
PART	CODE
Tooth Spring	SP7
Crank Return Spring	SP8
Brake Spring	SP3/3
Barrel Spring (takes stra wire when irrigator is trip	






PART	CODE
Brake Assembly	SP3
Brake Block	SP3/2
Spring	SP3/3
Galv Flat Washer	WSGF10
Splitpin	SP301

# WIRE LAYER









PART	CODE
Rotor Centre	SD114
Rotor Intermediate Extensions	SP115
Rotor Outer Extension (includes nozzle, clamp etc)	SP91
Stay Support Pole & Bolt	SP117
Stay Rod & Nuts	SP118
Stay Rod Adaptor	SP119
Nozzle quick release fittings male	SP1M
Nozzle quick release fitting female	SP1F
Power Nozzle with 13mm hole	SP1
Nozzle Clamp	SP2
Nozzle with Clamp and Quick Release Fittings	SP0
Rotor Seal 75 x 90 (3x per machine)	SEAL7590

# WIRE ACCESSORIES









SLEEVE5

VE5 THIMBLE5

SD120

SHACKLE4







**SP66** 





SP4

SP22 SP20

PART	CODE
Wire rope 5mm Galv per metre	WIRE5G
Wire rope 5mm SS per metre	WIRE5SS
5mm Sleeve (crimp)	SLEEVE5
5mm Thimble (eye)	THIMBLE5
Trip Wire	SD120
Trip Wire Shackle	SHACKLE4
Wire Guide (where the wire runs through on irrigator)	SP121
Anchoring Chain, Grab hook and D Shackle	SP66
Wire Guide Spring	SP7
Barrel Spring	SP21
Barrel Washer	SP22
Wire Stop (lets you stop the irrigator anywhere along the rope)	SP20

# **DRUM AND CRANK**



SD109

PART	CODE
Winch Drum Assembly	SD103
Crank Bracket	SD104
Speed Change Plate	SD105
Left Bearing Side Plate (includes bush)	SD108
Right Bearing Side Plate (includes bush)	SD109
Side Plate Nylon Bearing	SD110
Winch Crank Handle	SP4

### **WHEELS**



SD108

PART	CODE
Wheel Assembly	SP11
Wheel Bush/pair	SP11B
Wheel Lynch Pin	В3
20mm Galv Flat Washer	WSGF20

SD110

SP11

Wheel includes 19mm bushes. Spiders prior to 2004 require 20mm. Please state bush size when ordering.

# **TOW HITCH**



PART	CODE
Tow Hitch Assembly (incl bolts)	SP45

### **MAIN FRAME**



PART	CODE
Rear frame and axle	SD101
Front frame and draw bar	SD102
Skid	SD124